



12 MONTHS MAINTENANCE COVERAGE COE WITH AISIN TRANSMISSION (FROM 12MY)

5,000 km or 3 months

Retorque leaf spring u-bolts
Adjust brake pedal travel
Chassis lubrication
Lubricate door locks & hinges
Lubricate cab lock mechanism

10,000 km or 6 months

Replace engine oil & filter
Clean air filter element
Adjust belt tension
Check all fluid levels
Check steering wheel play
Check steering knuckle & tie-rods
Check brake pad/lining condition
Check service brake pedal play
Check service brake hoses & pipes
Check spring clamp pin fitting nut
Check spring u-bolt & spring band
Check shock absorber mounting nut
Check lamp operation
Check wipers & windshield washer
Check instrument lamp function
Check instrument gauge operation
Check wheels and retorque nuts
Chassis lubrication
Lubricate turbo control rod
Lubricate door locks & hinges
Lubricate cab lock mechanism
Clean cabin air filter

20,000 km or 9 months

Replace primary and secondary fuel filter
Replace CCV filter
Chassis lubrication
Check all fluid levels
Check brake pad/lining condition
Adjust belt tension
Check tire pressure
Check wheel nut torque
Check all lights
Clean air filter element
Adjust parking brake if required
Lubricate door locks & hinges
Lubricate cab lock mechanism

25,000 km or 12 months

Replace engine oil & filter
Chassis lubrication
Lubricate turbo control rod

30,000 km or 12 months

Chassis lubrication
Check all fluid levels
Check brake pad/lining condition
Adjust belt tension
Check tire pressure
Check wheel nut torque
Check all lights
Clean air filter element
Lubricate door locks & hinges
Lubricate cab lock mechanism
Clean cabin air filter

40,000 km

Replace engine oil & filter
Replace CCV filter
Chassis lubrication
Check all fluid levels
Check brake pad/lining condition
Adjust belt tension
Check tire pressure
Check wheel nut torque
Check all lights
Clean air filter element
Replace primary and secondary fuel filter
Replace transmission fluid
Adjust parking brake if required
Lubricate turbo control rod
Lubricate door locks & hinges
Lubricate cab lock mechanism
Clean cabin air filter

50,000 km

Chassis lubrication
Check all fluid levels
Check brake pad/lining condition
Adjust belt tension
Check tire pressure
Check wheel nut torque
Check all lights
Clean air filter element
Lubricate turbo control rod
Lubricate door locks & hinges
Lubricate cab lock mechanism
Clean cabin air filter



HINO PREMIUM PROTECTION



12-24 MONTHS MAINTENANCE SCHEDULE

14MY COE 155, 165, 195

55,000 km or 18 months complimentary service:

Replace engine oil & filter
Lubrication: Chassis, VNT and cab components

85,000 km or 30 months complimentary service:

Replace engine oil & filter
Lubrication: Chassis, VNT and cab components

60,000 km recommended service:

Chassis lubrication	Complimentary
Differential oil change	Complimentary
Power steering fluid - change	(\$)
Brake power booster oil change	(\$)
Replace primary and secondary fuel filter	(\$)
Replace CCV filter	(\$)
Replace air filter	(\$)
Replace all belts	(\$)

95,000 km complimentary:

Chassis lubrication

100,000 km or 36 months complimentary service:

Replace engine oil & filter
Lubrication: Chassis, VNT and cab components

70,000 km or 24 months complimentary service:

Replace engine oil & filter
Lubrication: Chassis, VNT and cab components

100,000 km recommended service:

Replace primary and secondary fuel filter	(\$)
Replace CCV filter	(\$)

80,000 km or 24 months recommended service:

Chassis lubrication	Complimentary
Replace transmission fluid	Complimentary
Replace clutch fluid (Hybrid only)	Complimentary
Repack wheel bearings	(\$)
Brake fluid flush	(\$)
Replace CCV filter	(\$)
Replace primary and secondary fuel filter	(\$)
Valve adjustment	(\$)



Scheduled service must be performed \pm 2000km of recommended interval



HINO PREMIUM PROTECTION



24-36 MONTHS MAINTENANCE SCHEDULE

14MY COE 155, 165, 195

110,000 km complimentary service:

Chassis Lubrication

115,000 km or 36 months complimentary service:

Replace engine oil & filter

Lubrication: Chassis, VNT and cab components

120,000 km recommended service:

Chassis lubrication

Differential oil change

Replace transmission fluid

Replace CCV filter

Replace clutch fluid (Hybrid only)

Replace primary and secondary fuel filter

Replace all belts

Power steering fluid - change

Brake power booster oil change

Complimentary

Complimentary

Complimentary

(\$)

(\$)

(\$)

(\$)

(\$)

(\$)

130,000 km complimentary service:

Replace engine oil & filter

Lubrication: Chassis, VNT and cab components

140,000 km recommended service:

Chassis lubrication

Replace primary and secondary fuel filter

Replace CCV filter

Complimentary

(\$)

(\$)

145,000 km complimentary service:

Replace Engine Oil & Filter

Lubrication: Chassis, VNT and cab components



Scheduled service must be performed \pm 2000km of recommended interval



12 MONTHS MAINTENANCE COVERAGE

258, 268, 338, 358

5,000 km or 3 months

- Replace transmission main filter (spin-on only)
- Replace engine oil & filter
- Clean power steering fluid reservoir strainer
- Replace power steering fluid & filter
- Retorque leaf spring u-bolts
- Adjust clutch and brake pedal travel
- Retorque wheel nuts
- Chassis lubrication
- Lubricate turbo control rod

10,000 km or 6 months

- Clean air filter element
- Check fan belt tension
- Check brake fluid level
- Check transmission fluid level
- Check differential gear oil level
- Check steering wheel play
- Check power steering fluid level
- Check steering knuckle & tie-rods
- Check brake pad/lining condition
- Adjust service brakes
- Check service brake pedal play
- Check service brake hoses & pipes
- Check spring clamp pin fitting nut
- Check spring u-bolt & spring band
- Check shock absorber mounting nut
- Check lamp operation
- Check wipers & windshield washer
- Check horn function
- Check instrumental lamp function
- Check instrument gauge operation
- Check wheels & retorque nuts
- Chassis lubrication
- Lubricate turbo control rod

20,000 km or 9 months

- Replace engine oil & filter
- Replace fuel filter (if required)
- Chassis lubrication
- Check all fluid levels
- Check brake pad/lining condition
- Clean air filter element
- Check tire pressure
- Retorque wheel nuts
- Check all lights
- Adjust belt tension
- Lubricate turbo control rod
- Replace CCV filter (from 11MY only)

30,000 km or 12 months

- Chassis lubrication
- Check all fluid levels
- Check brake pad/lining condition
- Adjust belt tension
- Check tire pressure
- Retorque wheel nuts
- Check all lights
- Clean air filter element
- Lubricate turbo control rod

40,000 km

- Replace engine oil & filter
- Replace fuel filter (if required)
- Chassis lubrication
- Check all fluid levels
- Check brake pad/lining condition
- Adjust belt tension
- Check tire pressure
- Retorque wheel nuts
- Clean air filter element
- Check all lights
- Lubricate turbo control rod
- Replace CCV filter (from 11MY only)

50,000 km

- Chassis lubrication
- Check all fluid levels
- Check brake pad/lining condition
- Adjust belt tension
- Check tire pressure
- Retorque wheel nuts
- Check all lights
- Replace front axle hub oil
- Replace air filter
- Lubricate turbo control rod



HINO PREMIUM PROTECTION



12-24 MONTHS MAINTENANCE SCHEDULE

14MY 258, 268, 338, 358

60,000 km or 18 months complimentary service:

Replace engine oil & filter
Lubrication: Chassis, VNT and cab components

60,000 km recommended service:

Replace fuel filter	(\$)
Power steering fluid - change	(\$)
Brake power booster oil change	(\$)
Replace CCV filter	(\$)
Replace all belts	(\$)
Replace front axle hub oil	(\$)

70,000 km complimentary service:

Chassis lubrication

80,000 km or 24 months complimentary service:

Replace engine oil & filter
Lubrication: Chassis, VNT and cab components

80,000 km or 24 months recommended service:

Replace fuel filter	(\$)
Valve adjustment	(\$)
Brake fluid flush	(\$)
Replace CCV filter	(\$)
Replace Allison transmission spin-on type filter	(\$)

90,000 km complimentary:

Chassis lubrication

100,000 km or 30 months complimentary service:

Replace engine oil & filter
Lubrication: Chassis, VNT and cab components

100,000 km recommended service:

Replace fuel filter	(\$)
Replace CCV filter	(\$)



Scheduled service must be performed \pm 2000km of recommended interval



HINO PREMIUM PROTECTION



24-36 MONTHS MAINTENANCE SCHEDULE

14MY 258, 268, 338, 358

110,000 km recommended service:

Chassis lubrication	Complimentary
Replace air filter	(\$)

120,000 km or 36 months complimentary service:

Replace engine oil & filter
 Lubrication: Chassis, VNT and cab components

120,000 km recommended service:

Replace fuel filter	(\$)
Replace CCV filter	(\$)
Power steering fluid - change	(\$)
Brake power booster oil change	(\$)
Replace all belts	(\$)
Replace front axle hub oil	(\$)
Replace Allison transmission internal; filter	(\$)

130,000 km complimentary service:

Chassis lubrication

140,000 km complimentary service:

Replace engine oil & filter
 Lubrication: Chassis, VNT and cab components

140,000 km recommended service:

Replace fuel filter	(\$)
Replace CCV filter	(\$)

150,000 km complimentary service:

Chassis lubrication	Complimentary
Differential oil change	



Scheduled service must be performed \pm 2000km of recommended interval



HINO PREMIUM PROTECTION



COE Recommended Maintenance Intervals for 2009MY and up

General vehicle Inspection	10,000km or 3 months
Engine oil - Hino genuine oil	15,000km or 6 months
CCV cannister filter	20,000km or 6 months
Primary & secondary fuel filters	20,000km or 6 months
Transmission fluid - change ¹	40,000km or 24 months
Belt replacement	60,000km or 24 months
Air filter replacement	60,000km or 24 months
Power steering fluid - change	60,000km or 24 months
Brake power booster oil change	60,000km or 24 months
Differential oil change (Non-synthetic oil only) ²	60,000km or 24 months
Valve adjustment	80,000km or 24 months
Repack wheel bearings	80,000km or 24 months or Brake Reline
Brake fluid flush	80,000km or 24 months
Replace DPR pressure differential switch hoses	240,000km or 36 months
DEF pump filter	240,000km or 36 months
Coolant flush	300,000km or 36 months

¹ Aisin Transmission requires ATF Type T-IV or equivalent from 2012MY
² Differential not approved for synthetic oil use

NAPS Recommended Maintenance Intervals for 2009MY and up

General vehicle inspection	10,000km or 3 months
Engine oil - Hino genuine oil (LDT)	15,000km or 6 months
Engine oil - Hino genuine oil (MDT)	20,000km or 6 months
CCV cannister filter (from 2011MY)	20,000km or 6 months
Air filter replacement	60,000km or 12 months
Belt replacement	60,000km or 24 months
Valve adjustment	80,000km or 24 months
Coolant flush	600,000km or 36 months
Fuel filter	20,000km or 6 months
Brake fluid flush	80,000km or 24 months
Transmission fluid - Change - Aisin	40,000km or 24 months
Transmission fluid - Change - Allison 1000/2000 Series ¹	240,000km or 48 months
Transmission fluid filter - Replace - Allison 1000/2000 Series ¹	80,000km or 24 months
Transmission fluid - Change - Allison 3000 Series ¹	480,000km or 48 months
Transmission fluid filter - Replace - Allison 3000 Series ¹	120,000km or 36 months
Transmission fluid - Change - Eaton ¹	400,000km or 36 months
Replace front axle hub oil ²	160,000kms or 12 months or brake reline
Differential oil change - synthetic ³	400,000km or 36 months
Power steering fluid - Change	60,000km or 24 months
Replace DPR pressure differential switch hoses	240,000km or 36 months
DEF pump filter: replace	240,000km or 36 months
DPR burner fuel injector nozzle: inspect/replace	240,000km
DPR burner flame sensor: inspect/replace	240,000km
DPR burner fuel filter: replace	100,000km or 24 months

¹ Transmission factory filled with approved synthetic oil from 2007MY and newer
² Synthetic oil used in front axle hubs from 2009MY (LDT) and 2006MY (MDT)
³ Differential factory filled with approved synthetic fluid from 2009MY and newer